# Lab 7

System Administration

### **Scenario:**

Create the following groups:

- writers
- tv
- movie

Create 10 user accounts (User1, User2, ..., User10). Ensure that:

- All users are added to the default group writers.
- Some users are also added to the tv group.
- Other users are added to the movie group.

Create a text file named example.txt and edit it using either the Vi or Nano editor.

## **Solution:**

- 1. Create the following groups:
- sudo groupadd writers
- sudo groupadd tv
- . sudo groupadd movie



### **Solution:**

- 2. Create 10 user accounts ....
- for i in {1..10}; do
- sudo useradd -G writers user\$i
- done

- sudo usermod -aG tv user1
- sudo usermod -aG tv user2
- sudo usermod -aG tv user3

- sudo usermod -aG movie user4
- sudo usermod -aG movie user5
- sudo usermod -aG movie user6

momik@pop-os: ~ Q ≣ n momik@pop-os:~\$ # Create users with the default group 'writers' for i in {1..10}; do sudo useradd -G writers user\$i done # Add User1, User2, and User3 to the 'tv' group sudo usermod -aG tv user1 sudo usermod -aG tv user2 sudo usermod -aG tv user3 # Add User4, User5, and User6 to the 'movie' group sudo usermod -aG movie user4 sudo usermod -aG movie user5 sudo usermod -aG movie user6 momik@pop-os:~\$

## **Solution:**

2. Create a text file named example.txt and edit it using either the Vi or Nano editor.

touch example.txt nano example.txt





